

P20D RTK
Positioning and Heading
Module

V1.5

REVISIONS

| Version | Release notes | Dates |
|----------------|---|--------------|
| R1.0 | Beta version | 2022-12-09 |
| R1.1 | Add protocols GPHPR, GPIMU | 2023-03-14 |
| R1.2 | Add protocols HDT, ROT, SXT | 2023-03-23 |
| R1.3 | Add protocol FMI, add dual antenna installation notes, add module picture | 2023-06-06 |
| R1.4 | Add support for 10Hz RTK, enable 3 UART outputs | 2023-09-04 |
| R1.5 | 12#13# Pin definition correction | 2024-04-07 |

Table of Contents

| | |
|-------------------------------------|---|
| 1. Introductions | 1 |
| 2. Features | 1 |
| 3. Parameters | 2 |
| 4. Pin definition | 3 |
| 5. Antenna features | 4 |
| 6. Commands | 5 |
| 7. Packaging | 7 |
| 8. Manufacturing Requirements | 8 |
| 9. Message protocols | 9 |

1. Introductions

P20D is a high-precision GNSS RTK positioning and heading module. It can simultaneously track multiple frequencies of all GNSS constellations (GPS, BDS2, BDS3, GALILEO, GLONASS, QZSS), and the module can perform on-chip RTK positioning and dual-antenna heading calculation. P20D has integrated an industrial 6-axis IMU sensor that can maintain correct heading and attitude information for harsh GNSS signal reception environment.

P20D is a perfect choice for high-precision navigation and Positioning applications such as UAV, machine control, precision agriculture and marine, that demands the highest stability and integrity in heading and attitude.




2. Features

- 12nm technology, most advanced in industry.
- Supports RTK between master and slave antenna for heading operation, with antenna separation as close as 5 cm
- 21 mm x 16 mm x 2.6 mm, the smallest integrated heading module
- Lowest power RTK & heading module (100mW peak power) in the world
- Supports dual mode operation (base station/rover mode)
- Full constellations and multiple frequencies

3. Parameters

| Category | Performance index | |
|--------------------|--|------------------------------|
| Receive Type | GPS/QZSS: L1/L5 | |
| | BeiDou: B1I/B2a | |
| | GALILEO: E1/E5a | |
| | GLONASS: G1 | |
| Nav. update rate | RTK: 1Hz/2Hz/5Hz/10Hz IMU: 50Hz/100Hz | |
| sensitivity | Tracking & Nav. | -165dBm |
| | Reacquisition | -160dBm |
| | Capture sensitivity | -148dBm |
| Acquisition | cold starts | 27s 5s with AGNSS |
| | hot starts | 1s |
| Heading accuracy | 0.2 degrees/1m baseline | |
| Position accuracy | 1cm + 1ppm | |
| Altitude accuracy | 2cm + 1ppm | |
| Operational limits | Velocity | 515m/s |
| | Altitude | 18km |
| Interface | UART | 3 (default baud rate 115200) |
| | PPS | 1 |
| Protocols | NMEA 0183 | |
| | RTCM 3.3 | |
| Electrical data | Supply voltage | 2.8V~4.3V (3.3V recommended) |
| | RF Antenna voltage | 3.3V |
| | Serial voltage | 2.8V |
| | PPS | 2.8V |
| power | 30mA*3.3V | |
| Operating temp | -40°C to 85°C | |
| Storage temp | -40°C to 90°C | |
| humidity | 95% non-condensing | |
| Package | 21 mm x 16 mm x 2.6 mm | |

4. Pin definition



| Pin NO | name | I/O | Descriptive |
|--------|----------|-------|--|
| 1 | GND | - | Ground |
| 2 | ANT1_IN | I | GNSS antenna signal input (main antenna) |
| 3~4 | GND | - | ground |
| 5~13 | NC | - | Reserved, floating |
| 14 | ERR_STAT | O | Abnormal status output, active high |
| 15 | PVT_STAT | O | PVT positioning indication, active high |
| 16 | RTK_STAT | O | RTK position indication, active high |
| 17 | RXD0 | I | Serial 0 receive |
| 18 | TXD0 | O | Serial 0 Transmit |
| 19 | RXD1 | I | Serial port 1 receive |
| 20 | TXD1 | O | Serial port 1 Transmit |
| 21~22 | NC | - | vacancy |
| 23 | VCC | POWER | Voltage supply 3.3V |
| 24 | VCC | POWER | Voltage supply 3.3V |
| 25~26 | NC | - | vacancy |

| | | | |
|-------|----------|---|--|
| 27 | TXD2 | O | Serial port 2 Transmit |
| 28 | RXD2 | I | Serial port 2 receive |
| 29 | NC | - | vacancy |
| 30 | PPS | O | second pulse (physics) |
| 31 | NC | - | vacancy |
| 32 | RTC_EINT | I | Low Power Wakeup |
| 33 | RESET | I | system reset |
| 34~35 | GND | - | ground |
| 36 | ANT2_IN | I | GNSS antenna signal input (from antenna) |
| 37 | GND | - | ground |
| 38~40 | NC | - | vacancy |
| 41 | GND | - | ground |
| 42 | NC | - | vacancy |
| 43 | GND | - | ground |
| 44 | NC | - | vacancy |
| 45 | GND | - | ground |
| 46~48 | NC | - | vacancy |

5. Antenna features

| Parameters | min | max | unit |
|------------|-----|-----|------|
| Input Gain | 18 | 23 | dB |

6. Commands

| | |
|----------------------|---|
| AT+GPGGA=n | Select serial port to output GGA every n epochs |
| AT+GPRMC=n | Select serial port to output RMC every n epochs |
| AT+GPSAT=n | Select serial port to output GSV/GSA every n epochs |
| AT+GPGST=n | Select serial port to output GST every n epochs |
| AT+GPGLL=n | Select serial port to output GLL every n epochs |
| AT+GPVTG=n | Select serial port to output VTG every n epochs |
| AT+GPZDA=n | Select serial port to output ZDA every n epochs |
| AT+GPHDT=n | Select serial port to output HDT every n epochs |
| AT+GPROT=n | Select serial port to output ROT every n epochs |
| AT+GPTHS=n | Select serial port to output THS every n epochs |
| AT+GPSXT=n | Select serial port to output SXT every n epochs |
| AT+GPFMI=n | Select serial port to output FMI every n epochs (upgrade to new firmware version required) |
| AT+GPHPR=n | Select serial port to output HPR every n epochs(1~ 100Hz) |
| AT+GPIMU=n | Select serial port to output IMU every n epochs(1~ 100Hz) (1~ 100Hz) |
| AT+IMU_RATE= 100 | Set internal IMU update frequency (50Hz, 100Hz) Default 50Hz |
| AT+IMU_ANGLE=x,y,z | Setting the module mounting angle, see the module mounting help manual for details, reboot required |
| AT+YAW_ANGLE=0,0,z | Set the dual antenna mounting rotation angle (z is the rotation angle) (following a right-handed coordinate system, with the thumb pointing in the positive direction of the z-axis, clockwise is positive, and the dual antenna direction is steered in the direction of carrier motion) |
| AT+RTCM= 1/0 | Output RTCM3 Obs Data (1:open,0:close) |
| AT+NAVI_RATE= 1 | Set Nav update rate 1Hz Support 1/2/5Hz, need cold restart |
| AT+UARTOFF=UART0/1 | Stop all output of the select serial port |
| AT+BAUD_RATE= 115200 | Set the serial port baud rate Need cold restar (supports 460800, 921600) |
| AT+READ_PARA | Read mode parameters |
| AT+THIS_PORT | Read the current serial port number |

| | |
|------------------|---|
| AT+WARM_RESET | Warm restart |
| AT+COLD_RESET | Cold restart (some commands require Cold restart to take effect) |
| AT+RTC_MODE=n | enter standby mode, n is the time (in seconds) to keep the RTC in sleep mode, the Minimum valid time is 10 seconds, if set to 0, hardware wakeup is required. |
| AT+NMEA_HEAD=0/1 | 0: statements such as GGA begin with GN, 1: begin with GP (default 0) |

Default baud rate 115200, commands end in \r\n. Compatible P20M Command Format

Notes on module and dual antenna installation:

1. P20D has an integrated imu, therefore the module needs to be rigidly installed with the host vehicle. There should be no relative motion between P20D module and the master/slave antennas.

2. The default orientation when installing the module is where the arrow on the module label is pointing (as shown in the picture below) towards the direction of the carrier's movement, with the top of the module pointing towards the sky and the back of the module pointing towards the ground.


3. Configuration Commands exist to allow for different orientations when the above installations can not be made.

AT + IMU_ANGLE = x,y,z for the module mounting angle configuration (you can refer to the P20X module mounting user manual)




4. If the dual-antenna direction is not consistent with the forward direction of the vehicle, it is necessary to adjust the dual-antenna angle to ensure that it is consistent with the direction of the vehicle, send the command AT+YAW_ANGLE=0,0,z to configure (z is the angle of rotation, following the right-handed coordinate system, with the thumb pointing in the positive direction of the z-axis, and the clockwise direction is positive, and the direction of the dual-antenna is shifted towards the direction of the vehicle movement)

7. Packaging



| Symbol | Min.(mm) | Typ.(mm) | Max.(mm) |
|--------|----------|----------|----------|
| A | 20.80 | 21.00 | 21.50 |
| B | 15.80 | 16.00 | 16.50 |
| C | 2.40 | 2.60 | 2.80 |
| D | 2.78 | 2.88 | 2.98 |
| E | 0.95 | 1.05 | 1.15 |
| F | 1.55 | 1.65 | 1.75 |
| G | 1.17 | 1.27 | 1.37 |
| H | 0.70 | 0.80 | 0.90 |
| K | 1.40 | 1.50 | 1.60 |
| M | 4.10 | 4.20 | 4.30 |
| N | 3.70 | 3.80 | 3.90 |
| P | 2.05 | 2.10 | 2.15 |
| R | 0.90 | 1.00 | 1.10 |

8. Manufacturing Requirements



Furnace Temperature Schematic

Warm-up phase:

Temperature rise rate: max 3°C/S. If the temperature rise is too fast, it may result in a larger paste slump.

Preheating time: 60~ 120 S. Insufficient preheating will produce large solder balls, on the contrary, if preheating is too long, solder balls will be gathered and produced.

Termination temperature: 150°C to 200°C. Too low a temperature and some areas with a high amount of hot melt will not melt.

Heating-Reflow stage:

Liquid temperature above 217°C. Avoid a sudden rise in temperature, which may cause the material to collapse.

Time over 217°C: 40-60S.

Peak temperature: 245°C.

Cooling phase:

Cooling control mainly avoids solder becoming more brittle and possible mechanical tension in the solder.

Cooling rate: max 4°C/S

9. Message protocols

(1) GPHPR

\$GPHPR,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>*<10><CR><LF>

<1> UTC time in the format hhmmss.sss

<2> Tow seconds in a week

<3> Roll angle (°)

<4> Pitch angle (°)

<5> Heading angle (°)

<6> Standard deviation of roll angle

<7> Standard deviation of pitch angle

<8> Standard deviation of heading angle

<9> Synchronized age

<10> heteroskedastic checksum

Example statement:

\$GNHPR,054913.004,193771.004,-0.391,0.009,69.434,0.123,0.123,0.018,0.204*5D

(2) GPIMU

\$GPIMU,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>*<9><CR><LF>

<1> UTC time in the format hhmmss.sss

<2> x-axis acceleration (g)

<3> y-axis acceleration (g)

<4> z-axis acceleration (g)

<5> Gyro x-axis orientation (°/s)

<6> Gyro y-axis orientation (°/s)

<7> Gyro z-axis orientation (°/s)

<8> Sensor temperature (°C)

<9> heteroskedastic checksum

Example statement:

\$GPIMU,054752.002,0.000,0.007,-1.032,-0.003,0.053,-0.016,26.00*59

(3) GNSXT

\$GNSXT,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,<10>*<11><CR>& LF>

<1> utc time hhmmss.sss

<2> Distance from antenna to main antenna (m)

<3> North-facing position with the main antenna as origin (m)

<4> Easterly position with the main antenna as origin (m)

<5> Zenithward position with the main antenna as origin (m)

<6> Standard deviation of the northward position

<7> Standard deviation of the eastward position

- <8> Standard deviation of zenith to position
- <9> Number of satellites used for settlement from antennas
- <10> Localization quality from antenna (0: not available, 4: fixed solution)
- <11> checksum

Example statement:

\$GNSXT,032423.200,9.903,3.484,9.270,-0.003,0.012,0.022,0.015,31,4*7B

(4) GPFMI

\$GPFMI,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,<10>,<11>,<12>.

<13>,<14>,<15>,<16>,<17>,<18>,<19>,<20>,<21>,<22>,<23>[,<E1&
gt;~<E10>]*<24><CR><LF>

- <1> UTC time in the format hhmmss.ss. ss
 - <2> Week number.
 - <3> Time of week, seconds of week, in the format (ss.mmm)
 - <4> Latitude in degrees. Positive numbers are north latitude, negative numbers are south latitude
 - <5> Longitude, in degrees. Positive numbers are east longitude, negative numbers are west longitude.
 - <6> Elevation, in meters
 - <7> Standard deviation of latitude, in meters
 - <8> Standard deviation of longitude, in meters
 - <9> Standard deviation of elevation, in meters
 - <10> Velocity eastward in meters per second (m/s)
 - <11> Velocity northward in meters per second (m/s)
 - <12> Velocity in zenith direction, in meters per second (m/s)
 - <13> Standard deviation of horizontal velocity, in m/s
 - <14> Angle of heading, in degrees
 - <15> Pitch angle, in degrees
 - <16> Traverse roll angle, in degrees
 - <17> Standard deviation of heading angle, in degrees
 - <18> Standard deviation of pitch angle, in degrees
 - <19> Standard deviation of roll angle, in degrees
 - <20> Baseline distance in meters
 - <21> Number of satellites visible from the antenna
 - <22> The number of observations fixed throughout the carrier week is only meaningful for fixed solutions
 - <23> Positioning quality indication, 0=invalid solution, 1=single point solution, 2=differential solution, 4=fixed solution, 5=floating point solution, 6=inertial guidance solution
- If you set the FMI statement to expand, you will append 10 expansion fields
- <E1> Fixed solution reference Ratio

- <E2> Number of fixed-solution AR double-difference fuzzy degrees
- <E3> Carrier-to-noise ratio average
- <E4> Number of carrier non-integer observations
- <E5> Number of delta observations
- <E6> Reserved
- <E7> Reserved
- <E8> Reserved
- <E9> Reserved
- <E10> Reserved
- <24> heteroskedastic checksum

Sample Statement (with Extended Fields)

\$GPFMI,092900.20,2248,466158.200,42.06414612,106.22805621,154.305,0.0077,0.0068,0.0
166,-0.006,0.005,0.033,0.012,0.00,0.00,0.00, - 1.0000,-1.0000,-
1.0000,185.578,38,40,4,1.74,19,43,,,,,,*4C